Aprilia ETV 1000 Capanord

= Connector 1
= Connector 2
= Connector 3

All connectors are together in large rubber boot below right hand side of throttle body

15A Secondary Fuses

A - Headlight (high/low beam), Dashboard
B - Fuel Pump
C - Parking Lights, Rear Stoplight, Horn, Direction Indicators
D - Start, Safety Logic
E - Free, Accessory Outlet

Speed Sensor
High Beam Relay
Low Beam Relay
Warning Horn
Left Handlebar Switches
Indicator Relay
Air Temp Sensor Dash
Coolant Temp Sensor Dash
Oil Pressure Switch
Right Handlebar Switches
Front Brake Light Switch
Ignition Switch
Engine Cutout Relay
Fuel Pump Relay

ASD Version

Front Right Indicator
High Beam
High Beam
Low Beam
Parking Light
Front Left Indicator

Rear Right Indicator
Parking / Brake Lights
Rear Left Indicator
Rear Brake Light Switch
Licence Plate Light

Diagnostic Connection

ECU
P1
P2

Test Mode Connector

Diode

Bank Angle Sensor

Secondary Fuses
Accessory Outlet
Main Fuses

Idle Stabilizer Valve
Coils
Throttle Valve Position Sensor
Coolant Temp Sensor ECU
Air Temp Sensor ECU
Fuel Pump
Fuel Sender
Cooling Fan
Fuel Injectors
Purge Valve (CA)
Injection Relay
Rectifier / Regulator
Alternator
Crankshaft Pickup Coil
Battery
Starter Solenoid
Starter Motor
Side Stand Switch
Neutral Switch
Clutch Switch
Diode Module

Revision 1.00

© Chris Elms 2011